

ČÍSLO	SOUŘADNICE X	SOUŘADNICE Y
101	- 684247093,3641	- 1163552097,7602
102	- 684247408,7032	- 1163552948,9026
103	- 684240180,0000	- 1163554700,0000
104	- 684239210,0000	- 1163555190,0000
105	- 684237750,0000	- 1163557770,0000
106	- 684236800,0000	- 1163561310,0000
107	- 684236833,0234	- 1163589201,2548
108	- 684230705,0904	- 1163610892,1820

## **KANALIZACE - VPUSTI + ŠACHTY**

ČÍSLO	SOUŘADNICE X	SOUŘADNICE Y
1	- 684133178,1672	- 1163657972,3539
2	- 684151924,0062	- 1163645214,7759
3	- 684187608,6575	- 1163632294,8074
4	- 684193434,4427	- 1163636054,1184
5	- 684202696,6376	- 1163626822,9395
6	- 684230579,4005	- 1163627863,9808
7	- 684231403,9077	- 1163602977,2872
8	- 684234531,9934	- 1163577218,8069
9	- 684135835,8183	- 1163654057,9424
10	- 684177944,9146	- 1163639005,7416
11	- 684223133,2458	- 1163622697,8583
12	- 684226918,7836	- 1163632872,4726
13	- 684236709,7065	- 1163659312,3820
14	- 684231765,2599	- 1163664963,3975
15	- 684227551,7667	- 1163616588,5742
16	- 684233771,3803	- 1163573988,9349

Pozn.: Hodnoty vytyčovacích bodů jsou v mm